



Ben Liu

Mobile/ WeChat: +86-13705041170

FUZHOU SUNSHINE MACHINERY CO.,LTD

NO.6 Gulouyuan, Juyuanzhou Industrial Zone,

Jinshan Development Area, Fuzhou, Fujian, China.

Email: sales@primepowergenset.com

<http://www.gensetengine.com>

Cummins 4B3.9 engine Spare parts catalog

Part number	Description
3978822	BEARINGCRANKSHAFT THRUST
3978818	Bearing, Main (Upper: Standard)
5264569	GASKET
3963983	WASHERSEALING
3935449	ISOLATORNOISE
3902332	KEYPLAIN WOODRUFF
3902425	WASHERSEALING
3910739	BEARINGBALL
4891178	SUPPORTCAMSHAFT THRUST
3927692	NUTHEAVY HEXAGON
3918188	WASHERSEALING
3923044	RETAINERFAN HUB
4942278	SEAL,BANJO CONNECTOR
3938157	GASKETFLANGE
3007635	PLUGEXPANSION
3008468	PLUGPIPE
3037236	SEAL,O RING
2830411	SCREWHEX FLANGE HEAD CAP
2881890	TURBOCHARGERHY30W
3281246	BRACKETLIFTING
3284377	RODPUSH
3286278	PUMP,WATER
3286872	ELBOWMALE ADAPTER
3289941	BELTV RIBBED

3408645	SWITCHTHERMO
3504967	WASHERPLAIN
3519163	SCREWDRIVE
3519304	SHIELDTURBOCHARGER HEAT
3522597	PINROLL
3527566	RINGRETAINING
3527619	DATAPLATE
3528104	BAFFLEOIL
3528121	COUPLINGELBOW HOSE
3528177	END, ADJUSTING LINK
3528204	NUTLOCK
3528221	RINGRETAINING
3528933	SEALO RING
3530556	SCREWHEXAGON HEAD SET
3530923	PLATEOIL SEAL
3530924	SLINGEROIL
3532195	SPACERMOUNTING
3532940	SCREWHEXAGON HEAD SET
3534451	COLLARTHRUST
3535001	GASKETTURBOCHARGER
3535203	BRACKETACTUATOR
3535215	CLAMPHOSE
3535800	RINGRETAINING
3539805	WHEELTURBOCHARGER
3590296	BOLTT
3590606	CLAMPV BAND
3592050	NUTHEXAGON FLANGE
3595651	BEARINGTUR THRUST
3596402	NUTLOCK
3600815	SCREWHEXAGON HEAD CAP
3756754	SEALSPLIT RING
3758848	SEALSPLIT RING
3762259	RINGRETAINING
3802421	SETPISTON RING
3802561	KITENGINE PISTON
3818823	STUD
3818824	NUTREGULAR HEXAGON
3883244	NUTREGULAR HEXAGON
3900068	DOWELRING
3900227	SCREWHEXAGON HEAD CAP
3900242	RINGRETAINING
3900245	WASHERPLAIN
3900257	DOWELPIN
3900269	WASHERPLAIN
3900623	SCREWHEXAGON HEAD CAP

3900630	SCREWHEX FLANGE HEAD CAP
3900631	SCREWHEX FLANGE HEAD CAP
3900632	SCREW,HEX FLANGE HEAD CAP
3900677	SCREWHEXAGON HEAD CAP
3900678	SCREWHEX FLANGE HEAD CAP
3900687	PLUGEXPANSION
3900955	PLUGEXPANSION
3900965	PLUGEXPANSION
3901049	PANOIL
3901221	SCREWHEXAGON HEAD CAP
3969562	Bearing, Connecting Rod (Standard)
3901249	SCREWHEX FLANGE HEAD CAP
3901395	SCREWHEXAGON HEAD CAP
3901774	GEARFLYWHEEL RING
3901859	SCREWHEX FLANGE HEAD CAP
3901895	CAPFILLER
3902343	DOWELRING
3903035	SCREW,BANJO CONNECTOR
3903096	SCREWHEX FLANGE HEAD CAP
3903210	NUTHEXAGON FLANGE
3903463	COVERACCESS HOLE
3903475	SEALRECTANGULAR RING
3903723	WASHERPLAIN
3903857	SCREWHEX FLANGE HEAD CAP
3903990	SCREWHEX FLANGE HEAD CAP
3904217	SCREWHEXAGON HEAD CAP
3904483	PINROLL
3904531	RINGCOMPRESSION PISTON
3904692	CONNECTIONSPACER
3904711	BRACETUBE
3905307	SCREWBANJO CONNECTOR
3905391	SEALGROMMET
3906619	PLUGPIPE
3906694	SEALRECTANGULAR RING
3906696	SEALRECTANGULAR RING
3906698	SEALRECTANGULAR RING
3907049	SCREWHEX FLANGE HEAD CAP
3907769	SCREWHEXAGON HEAD CAP
3909355	ADAPTERFILTER HEAD
3909356	SEALRECTANGULAR RING
3910495	SCREWHEX FLANGE HEAD CAP
3910530	GASKETWTR TRF CONNECTION
3910810	LEVERROCKER
3910811	LEVERROCKER
3910824	SEALO RING

3911423	SUPPORTROCKER LEVER
3914459	PULLEYFAN
3915787	PLUGTHREADED
3916436	DAMPERRUBBER VIBRATION
3917717	BRACETUBE
3917746	ISOLATORVIBRATION
3918315	RINGCOMPRESSION PISTON
3918427	SPRINGCOMPRESSION
3918428	PLUNGERPRS REGULATOR
3918951	CLAMPV BAND
3918952	SEALO RING
3918954	HEADLUB OIL FILTER
3919369	GASKETTURBOCHARGER
3919864	SCREWHEX FLANGE HEAD CAP
3919952	SCREWHEX FLANGE HEAD CAP
3920400	SCREWHEX FLANGE HEAD CAP
3920691	RINGRETAINING
3920773	WASHERSEALING
3920781	SCREWHEX FLANGE HEAD CAP
3920795	CONNECTIONOIL SUCTION
3921644	CONNECTIONOIL FILLER
3922488	SUPPORTROCKER LEVER
3923303	HARNESSWIRING
3923331	GASKETTHM HOUSING COVER
3924147	PLUGTHREADED
3924148	PLUGTHREADED
3924724	SCREWBANJO CONNECTOR
3925226	CONNECTIONWATER TRANSFER
3926631	PISTON ONLY
3926863	SCREWHEX FLANGE HEAD CAP
3928404	COVERVALVE
3928405	COVERVALVE
3928759	SEALGROMMET
3929017	BEARING,MAIN (010)
4938934	BEARING, MAIN (0,50 mm)
4938937	Bearing, Main (0,25 mm)
4938938	
3929027	GEARCRANKSHAFT
3929028	GEARCAMSHAFT
3929036	CRANSHAFT,4B
3929457	SEALO RING
3929885	CAMSHAFT
3930906	GASKETVALVE COVER
3932520	RINGOIL PISTON
3933364	DIPSTICK

3934047	PIN,PISTON
4943979	ROD,ENGINE CONNECTING
3936365	VALVEPRESSURE RELIEF
3936876	SEALRECTANGULAR RING
3937214	NOZZLEPISTON COOLING
3937438	SCREWRKR LEVER ADJUSTING
5333477	TENSIONER,BELT
3937706	GASKET,OIL DRAIN
3938162	GASKETOIL PAN
3939258	GASKETCOVER PLATE
3941981	SCREWHEX FLANGE HEAD CAP
3942914	GASKET, OIL COOLER CORE B
3942915	GASKETFILTER HEAD
3957543	CORECOOLER
3959787	TUBEAIR FUEL CONTROL
3960901	PUMPFUEL INJECTION DELPH
3967250	SENSORTEMPERATURE
3967596	BEARING, MAIN (Standart)
3968470	SCREWTWELVE POINT CAP
3968986	TUBEOIL GAUGE
3969988	GASKETCONNECTION
3971615	MOTORSTARTING
3974406	TAG
3978820	BEARING, MAIN (Lower: Standard)
3991084	NAMEPLATE
4891179	SCREWCONNECTING ROD CAP
4893693	Bearing, Connecting Rod (Standard)
4903110	SCREWHEX FLANGE HEAD CAP
4930315	THERMOSTAT
4930591	SWITCH
4932124	GASKET,OIL COOLER CORE
4934023	
4934129	
4935789	MOTOR,STARTING
4936539	DECAL
4937405	PUMP,FUEL TRANSFER
4938310	PUMP,HYDRAULIC
4938436	BELT, V RIBBED
4938935	
4938936	
4938939	
4938940	
4938949	BEARING,CRANKSHAFT THRUST
4938950	BEARING,CRANKSHAFT THRUST
4938951	BEARING,CRANKSHAFT THRUST

4938952	BEARING,CRANKSHAFT THRUST
4938953	BEARING,CRANKSHAFT THRUST
4938954	BEARING,CRANKSHAFT THRUST
4943468	
4991816	BLOCK,CYLINDER
5255257	PISTON
5256371	CONTAINER, ENGINE
5268950	COMPRESSOR, AIR (1 CYL)
5272335	HUB, FAN
5282836	ALTERNATOR
5285750	HOSE, FLEXIBLE
LF3345	OIL FILTER (3908616)
4980120	TAG, INSTRUCTION
3972343	HEATER, INTAKE AIR
3415394	SCREWDRIVE
4992259	DATAPLATE
4991507	BLOCK, CYLINDER
3913917	CAP, MAIN BEARING
4991817	DOWEL, RING
4991818	CAP, MAIN BEARING
3922487	SHAFT, ROCKER LEVER
3910809	LEVER, ROCKER
3900705	INSERT, ROCKER LEVER
3910808	LEVER, ROCKER
3960376	CONNECTORMALE
3960377	ELBOWMALE ADAPTER
3960572	TUBECPR WATER OUTLET
4940557	TUBE, CPR WATER INLET
5265057	FLANGE, CRANKSHAFT
3967107	WASHERPLAIN
3967108	WASHERSPRING
3967131	WASHERSPRING
3967169	SCREWCROSSHEAD ADJUSTING
3976202	SUPPORTSTARTING AID
4932319	ALTERNATOR
4991553	SCREW, HEXAGON HEAD CAP
3967110	WASHERSPRING
3979347	SCREWHEXAGON HEAD CAP
4928957	SCREW, FLAT HEAD CAP
4930839	BRACKET, BELT TENSIONER
3973084	BRACEALTERNATOR
4932651	SUPPORT, ALTERNATOR
3976730	SUPPORTFAN
3415314	RING, RETAINING
3971367	SUPPORT, FAN

4937406	TUBE, FUEL SUPPLY
4928980	CONNECTOR, MALE
3903380	SEAL, BANJO CONNECTOR
4928946	SCREW, HEX FLANGE HEAD CAP
4934021	TUBE, FUEL DRAIN
4932608	TEE, MALE UNION
4934018	MANIFOLD, FUEL
4932532	TUBE, FUEL DRAIN
3917712	SCREW, HEXAGON HEAD CAP
4934024	TUBE, INJECTOR FUEL SUPPLY
4934025	TUBE, INJECTOR FUEL SUPPLY
4934026	BRACE, TUBE
4934130	TUBE, INJECTOR FUEL SUPPLY
4934131	TUBE, INJECTOR FUEL SUPPLY
4934134	BRACE, TUBE
4944053	FLYWHEEL
4944151	FLYWHEEL
4931172	DISC, COUPLING
3967421	ELBOWMALE ADAPTER
4938387	ELBOW, MALE UNION
4940349	PIPE, AIR TRANSFER
4938405	CONNECTION, AIR INTAKE
4931584	TAG, INSTRUCTION
4945477	DECAL
3924338	HEAD, LUB OIL FILTER
4937859	CLIP
3937027	PUMP, LUBRICATING OIL
3975389	CAMSHAFT
3975390	PISTON, ENGINE
4943467	INJECTOR
4040353	TURBOCHARGER
3599862	BEARING, TURBOCHARGER
3537560	ACTUATOR, TURBOCHARGER
3599669	IMPELLER, TUR COMPRESSOR
4038780	HOUSING, TUR BEARING
4050437	HOUSING, TURBINE
3539186	CONNECTION, ADAPTER
4048776	HOSE, PLAIN
3590300	HOUSING, COMPRESSOR
4936277	BRACKET, SHIPPING
4936541	COVER, DRIP
4929599	HOUSING, THERMOSTAT
3967286	SCREWHXAGON HEAD CAP
3967287	WASHERSPRING
3967288	WASHERPLAIN

3975807	BRACKETTHROTTLE CONTROL
4945010	BRACE, CONNECTION
3286275	KIT, WATER PUMP
3957139	TUBE FUEL SUPPLY