



Ben Liu
 Mobile/ WeChat: +86-13705041170
 FUZHOU SUNSHINE MACHINERY CO.,LTD
 NO.6 Gulouyuan, Juyuanzhou Industrial Zone,
 Jinshan Development Area, Fuzhou, Fujian, China.
 Email: sales@primepowergenset.com
<http://www.gensetengine.com>

Cummins 6CTA8.3 engine Spare parts catalog

Part number	Description
4089647	PUMP,WATER
5404408	KITLINER
5266243	ROD,ENGINE CONNECTING
4936026	THERMOSTAT
3934486	KITSEAL
4988747	PUMP,FUEL TRANSFER
3963983	WASHERSEALING
101322	CAPFILLER
S923E	DRAINCOCK
118227	DOWELFUEL PUMP
145530	SEALO RING
179901	VALVESHUTOFF
179903	COUPLINGELBOW HOSE
3004258	PLUG,EXPANSION
3900634	SCREWHEX FLANGE HEAD CAP
3902332	KEYPLAIN WOODRUFF
3902425	WASHERSEALING
3902468	CAPFILLER
3905194	RODPUSH
3906733	SCREWHEX FLANGE HEAD CAP
3909886	SEALINJECTOR
3910739	BEARINGBALL
3912900	PLUGEXPANSION
3916369	SCREWHEX FLANGE HEAD CAP
3919435	SHAFTROCKER LEVER
3919677	MANIFOLDOIL
3919918	RING,COMPRESSION PISTON
3920443	PLUGEXPANSION
3923478	CAMSHAFT

3926842	CONNECTIONTUR OIL DRAIN
4891178	SUPPORTCAMSHAFT THRUST
3927692	NUTHEAVY HEXAGON
3928870	BOLTCONNECTING ROD
3944153	BEARING,MAIN
3945967	PLUNGERPRS REGULATOR
3972757	RETAINERVALVE SPRING
3973493	HEADCYLINDER
3282141	SCREWBANJO CONNECTOR
3802474	KIT,ENGINE PISTON
3901617	SCREWTWELVE POINT CAP
3901693	CLAMPRETAINING
3901717	LEVERROCKER
3901969	PLUG,EXPANSION
3905870	SUPPORTROCKER LEVER
3911901	VALVECHECK
3918188	WASHERSEALING
3920692	RINGRETAINING
3924726	VALVECHECK
3925567	DAMPERRUBBER VIBRATION
3925863	GUIDEVALVE STEM
3934864	NUTREGULAR HEXAGON
3970951	BUSHING
3991085	SPRINGVALVE
3923044	RETAINERFAN HUB
3939352	GASKETOIL SUC CONNECTION
3911941	GASKETTURBOCHARGER
3936993	GASKETINT MANIFOLD COVER
3905449	SEALROCKER LEVER
3927642	SEALVALVE STEM
3938267	GASKETCYLINDER HEAD
3934046	PINPISTON
3945917	SETMAIN BEARING STD
4025270	KITSEAL
3918779	GASKETCONNECTION
3914310	GASKETTHERMOSTAT HOUSING
62392	WASHERPLAIN
3008465	PLUGPIPE
3008466	PLUGPIPE
3008468	PLUGPIPE
3008469	PLUGPIPE
3008470	PLUGPIPE
3037236	SEAL,O RING
3008464	PLUGPIPE
3035960	RINGRETAINING

3089238	PLUGTHREADED
3089240	SEAL,O RING
3093730	SCREW,HEX FLANGE HEAD CAP
3093775	SCREWHEX FLANGE HEAD CAP
3201562	SEALO RING
3282059	CLIP
3282372	STUD
3282433	SCREWHEX FLANGE HEAD CAP
3289325	BELTV RIBBED
3355406	HOSEPLAIN
3401544	ELM,FIL
3415317	HOSEFLEXIBLE
3415430	GEARCAMSHAFT
3415452	CAMSHAFT
3415501	GASKETCYLINDER HEAD
3415537	MOTORSTARTING
3503100	BEARINGTURBOCHARGER
3504967	WASHERPLAIN
3519163	SCREWDRIVE
3519302	SHIELDTURBOCHARGER HEAT
3522597	PINROLL
3522879	WHEELTURBOCHARGER H2
3527566	RINGRETAINING
3527619	DATAPLATE
3528104	BAFFLEOIL
3528121	COUPLINGELBOW HOSE
3528177	END, ADJUSTING LINK
3528221	RINGRETAINING
3528933	SEALO RING
3530556	SCREWHEXAGON HEAD SET
3530923	PLATEOIL SEAL
3530924	SLINGEROIL
3531238	RINGRETAINING
3532195	SPACERMOUNTING
3532196	SPACERMOUNTING
3532217	COLLARTHrust
3532298	SCREWHEXAGON HEAD SET
3532427	BAFFLE, TURBOCHARGER NOISE
3532940	SCREWHEXAGON HEAD SET
3535215	CLAMPHOSE
3535243	GASKETCONNECTION
3538468	HOSEPLAIN
3592050	NUTHEXAGON FLANGE
3595651	BEARINGTUR THRUST
3596402	NUTLOCK

3599592	IMPELLERTUR COMPRESSOR
3678786	SEAL,O RING
3678791	PLUG,THREADED
3678873	PLUGTHREADED
3678912	SEAL,O RING
3678921	PLUGTHREADED
3678923	PLUGTHREADED
3678925	SEAL,O RING
3756754	SEALSPLIT RING
3758848	SEALSPLIT RING
3759917	SCREWHEXAGON HEAD SET
3762259	RINGRETAINING
3802429	SETPISTON RING
3818823	STUD
3818824	NUTREGULAR HEXAGON
3863988	WASHERSEALING
3900227	SCREWHEXAGON HEAD CAP
3900240	NUTREGULAR HEXAGON
3900257	DOWELPIN
3900589	NUTHEXAGON FLANGE
3900623	SCREWHEXAGON HEAD CAP
3900626	SCREWHEX FLANGE HEAD CAP
3900628	SCREW,HEX FLANGE HEAD CAP
3900629	SCREWHEX FLANGE HEAD CAP
3900630	SCREWHEX FLANGE HEAD CAP
3900631	SCREWHEX FLANGE HEAD CAP
3900677	SCREWHEXAGON HEAD CAP
3901177	COLLETVALVE
3901249	SCREWHEX FLANGE HEAD CAP
3901445	SCREW,HEX FLANGE HEAD CAP
3901764	RINGRETAINING
3901846	DOWELPIN
3901865	SCREWHEX FLANGE HEAD CAP
3902460	SCREW,HEX FLANGE HEAD CAP
3902466	SEALRECTANGULAR RING
3903112	SCREWHEX FLANGE HEAD CAP
3903293	NUTREGULAR HEXAGON
3903463	COVERACCESS HOLE
3903464	SCREWHEX FLANGE HEAD CAP
3903475	SEALRECTANGULAR RING
3903546	SEALO RING
3903723	WASHERPLAIN
3903924	PINTIMING
3903990	SCREWHEX FLANGE HEAD CAP
3904483	PINROLL

3904519	BRACETUBE
3904711	BRACETUBE
3904849	RINGRETAINING
3905216	CLAMPV BAND
3905401	PLUGEXPANSION
3905408	TUBEOIL FILLER
3905804	BRACETUBE
3906100	WASHERSPRING
3906216	NUTHEXAGON FLANGE
3906436	TUBEWATER INLET
3906439	PLATECLAMPING
3906440	BRACKETLIFTING
3906619	PLUGPIPE
3906695	SEALRECTANGULAR RING
3907177	SEALRECTANGULAR RING
3907206	WASHERPLAIN
3907740	CLAMPSRING HOSE
3907769	SCREWHEXAGON HEAD CAP
3907860	SCREWHEX FLANGE HEAD CAP
3907861	BRACKETLIFTING
3907998	SCREWROUND HEAD CAP
3908095	PLATECOVER
3908110	PLUGTHREADED
3908402	TUBEWATER OUTLET
3908546	GEARFLYWHEEL RING
3909310	SCREWHEXAGON HEAD CAP
3909397	SEALO RING
3909557	BUSHINGREDUCING PIPE
3909669	TUBEBREATHER
3910248	PLUGO RING
3910260	SEALO RING
3910279	CLAMPINJECTOR
3910509	CLAMPHOSE
3910686	BRACETUBE
3910824	SEALO RING
3910960	WASHERPLAIN
3911446	SCREWBANJO CONNECTOR
3911924	HUB,FAN
3911925	COUPLINGPLAIN HOSE
3912072	SCREWHEXAGON HEAD CAP
3912473	SEALO RING
3913366	SCREWHEX FLANGE HEAD CAP
3913638	SCREWHEX FLANGE HEAD CAP
3913994	SEALO RING
3914708	LOCKPLATE

3914943	TUBEAIR
3915490	PLATECLAMPING
3915772	SEALRECTANGULAR RING
3916361	SCREWBANJO CONNECTOR
3917320	CRANKSHAFT,6C
3917394	CONNECTIONWATER TRANSFER
3917716	BRACETUBE
3917717	BRACETUBE
3917729	SCREWHEX FLANGE HEAD CAP
3917740	BRACETUBE
3917746	ISOLATORVIBRATION
3917747	ISOLATORVIBRATION
3917749	ISOLATORVIBRATION
3917776	BRACETUBE
3917892	GASKETCONNECTION
3918109	SCREWHEX FLANGE HEAD CAP
3918174	GASKETOIL COOLER CORE
3918334	HEADLUB OIL FILTER
3918539	TUBEFUEL SUPPLY
3918611	HOSEPLAIN
3918776	GEARCRANKSHAFT
3918785	BRACETUBE
3918786	ISOLATORVIBRATION
3919434	RIVET
3919683	HOUSINGTIMING
3920408	
3920447	SCREWHEX FLANGE HEAD CAP
3920595	MANIFOLDFUEL
3920622	SCREWHEX FLANGE HEAD CAP
3920706	PLUGEXPANSION
3920773	WASHERSEALING
3921357	BRACEFUEL PUMP
3921440	GASKETINT MANIFOLD COVER
3921652	TUBEFUEL DRAIN
3921719	CONNECTIONOIL SUCTION
3921816	SCREWHEX FLANGE HEAD CAP
3921919	RING,COMPRESSION PISTON
3922072	PLUGEXPANSION
3922639	SCREWHEX FLANGE HEAD CAP
3924147	PLUGTHREADED
3924148	PLUGTHREADED
3924389	WASHERSEALING
3924725	SCREWBANJO CONNECTOR
3925883	SCREWHEX FLANGE HEAD CAP
3925955	ADAPTERFILTER HEAD

3906081	KITSEAL
3926273	SUPPORTFUEL PUMP
3926722	SEAL,RECTANGULAR RING
3926781	SUPPORTFUEL PUMP
3926846	SCREWHEX FLANGE HEAD CAP
3926855	PULLEY,FAN
3926863	SCREWHEX FLANGE HEAD CAP
3926865	SPACERMOUNTING
3927611	BRACETUBE
3928031	NOZZLEPISTON COOLING
3928624	SEALO RING
3928629	CONNECTIONTUR OIL DRAIN
3928989	CLIP
3929011	GASKETLUB OIL CLR COVER
3929537	SCREWHEXAGON HEAD CAP
3930319	WASHERINSULATING
3930320	SCREWHEX FLANGE HEAD CAP
3930827	HOSEPLAIN
3930903	COVERVALVE
3930911	SEALO RING
3931084	PLUGTHREADED
3931380	GEARFUEL PUMP
3932063	GASKET,EXHAUST MANIFOLD
3933384	COVERREAR
3934410	VALVEBYPASS
3935113	CONNECTIONVENT
3936027	GASKETCOVER PLATE
5259022	TENSIONER,BELT
3936331	SEALRECTANGULAR RING
3936365	VALVEPRESSURE RELIEF
3937142	SEALINJECTOR
3937342	TUBEFUEL SUPPLY
3937438	SCREWRKR LEVER ADJUSTING
3937613	CLAMPSPRING HOSE
3937706	GASKET,OIL DRAIN
3938091	SUPPORTFUEL PUMP
3939258	GASKETCOVER PLATE
3939346	HEADCYLINDER
3939353	GASKETREAR COVER
3939356	GASKETSTARTER
3939570	SCREWCAPTIVE WASHER CAP
3940245	GASKETHYDRAULIC PUMP
3940246	PLATECOVER
3940386	SEAL, O RING
3941786	CARRIERSEAL

3942535	SEALOIL
5263529	SUPPORTFAN
3943808	PLUGEXPANSION
3943813	COVERGEAR
3943885	SCREWHX FLANGE HEAD CAP
3944158	BEARING,MAIN
3944163	BEARINGCRANKSHAFT THRUST
3944293	GASKETGEAR HOUSING
3944429	CONNECTIONWATER OUTLET
3945111	CONNECTIONWATER INLET
5283368	BUSHING
3945603	GASKETCONNECTION
3950661	BEARINGCON ROD STD
3960043	SCREW,HEX FLANGE HEAD CAP
3963988	WASHERSEALING
3966840	PUMPLUBRICATING OIL
3966976	SCREWHX FLANGE HEAD CAP
3968300	SWITCHPRESSURE
3968563	SEAL,OIL
3968988	TUBEOIL GAUGE
3969698	SEALRECTANGULAR RING
3970278	INSERTVALVE
3970407	HOSEPLAIN
3970655	SPRINGCOMPRESSION
3970886	GASKETBREATHER
3972266	TIMEROVERCRANK
4376359	PUMP,WATER
3973459	TUBE, INJECTOR FUEL SUPPLY
3973460	TUBE, INJECTOR FUEL SUPPLY
3973461	TUBE, INJECTOR FUEL SUPPLY
3973462	TUBE, INJECTOR FUEL SUPPLY
3973463	TUBE, INJECTOR FUEL SUPPLY
3973464	TUBE, INJECTOR FUEL SUPPLY
3973497	FLYWHEEL
3973509	GASKETOIL PAN
3974291	PANOIL
3974406	TAG
3974815	CORECOOLER
3975443	TAG, IDENTIFICATION
3975596	HOSEPLAIN
3975597	HOSEPLAIN
3979176	SENSORTEMPERATURE
3991084	NAMEPLATE
3991306	SCREWHX FLANGE HEAD CAP
3992092	GASKETCONNECTION

4010643	SEALO RING
4024883	KITSEAL
4025271	SETUPPER ENGINE GASKET
4049835	TURBOCHARGER
4058964	RESISTOR,CORROSION
4089889	SETLOWER ENGINE GASKET
4894641	SCREWCAPTIVE WASHER CAP
4936967	SEAL, RECTANGULAR RING
4940384	PLATE,COVER
4941322	THERMOSTAT
4942879	SOLENOID,FUEL PUMP
4946714	NUT,LOCK
4948364	INJECTOR
4980085	SEAL,RECTANGULAR RING
4989873	PUMP, FUEL
70622	CLIP
FF42000	Filter, Fuel
3930942	FUEL FILTER (3930942)
4980120	TAG, INSTRUCTION
3415394	SCREWDRIVE
4992259	DATAPLATE
3903380	SEAL, BANJO CONNECTOR
3917712	SCREW, HEXAGON HEAD CAP
3678924	PLUG, THREADED
3089239	PLUG, THREADED
3678922	PLUG, THREADED
3913995	HOUSING, TIMING PIN
3905860	SCREW, BANJO CONNECTOR
3897329	BALL
3902588	INSERT, ROCKER LEVER
3926429	LEVER, ROCKER
3919433	SHAFT, ROCKER LEVER
3936058	CAP, MAIN BEARING
3942895	SUPPORT, FAN
3930910	PLUG, THREADED
3974325	HEAD, LUB OIL FILTER
3931077	COVER, LUB OIL COOLER
3934278	VALVE, BYPASS
3924350	ROD, ENGINE CONNECTING
3924492	VALVE, INTAKE
3921444	VALVE, EXHAUST
3908141	TOOL, SEAL INSTALLATION
4942815	HEATER, INTAKE AIR
3939313	BLOCK, CYLINDER
3939311	BLOCK, CYLINDER

3802211	SET, MAIN BEARING
3916841	BEARING, MAIN
3923569	BEARING, CRANKSHAFT THRUST
3901591	BEARING, MAIN
3802212	SET, MAIN BEARING
3916842	BEARING, MAIN
3923570	BEARING, CRANKSHAFT THRUST
3901592	BEARING, MAIN
3802213	SET, MAIN BEARING
3916843	BEARING, MAIN
3923571	BEARING, CRANKSHAFT THRUST
3901593	BEARING, MAIN
3802214	SET, MAIN BEARING
3916844	BEARING, MAIN
3923572	BEARING, CRANKSHAFT THRUST
3901594	BEARING, MAIN
3921544	BEARING, CRANKSHAFT THRUST
3921545	BEARING, CRANKSHAFT THRUST
3921546	BEARING, CRANKSHAFT THRUST
3938086	HOUSING, GEAR
5255180	CLAMP, SPRING HOSE
4932506	WIRE, GROUND
3415336	CONNECTORMALE
3415457	TUBEAIR FUEL CONTROL
3975392	ELBOWMALE ADAPTER
4989118	HEAD, FUEL FILTER
4934598	ADAPTER, FILTER HEAD
4989115	HEAD, FUEL FILTER
4943504	COVER, REAR
5253951	HOUSING, FLYWHEEL
3415320	HOUSING, FLYWHEEL
3415478	PLUGORIFICE
3415598	SPACERMOUNTING
4988581	NUT, HEXAGON FLANGE
3974945	SPACER, MOUNTING
3973496	FLYWHEEL
3938077	NUT, LOCK
4936396	HEAD, LUB OIL FILTER
3905821	PIECE
4935907	CLIP
3945806	DIPSTICK
3916103	TAG, INSTRUCTION
3908830	INSERT, VALVE
3936155	HEAD, CYLINDER
3922686	RING, COMPRESSION PISTON

3973458	TUBE, INJECTOR FUEL SUPPLY
3969700	BRACE, TUBE
4046271	TURBOCHARGER
4029412	HOUSING, TURBINE
4035136	HOUSING, TUR BEARING
4040154	ACTUATOR, TURBOCHARGER
4050384	CONNECTION, ADAPTER
4050534	HOUSING, COMPRESSOR
4944603	ELBOW, PLAIN STREET PIPE
3974262	VALVE, CHECK
3908321	SCREW, TWELVE POINT CAP
3929779	MANIFOLD, EXHAUST
3978993	CLAMPT BOLT
3415334	DECAL
3415552	DRAINCOCK
4947675	AFTERCOOLER
3967594	SCREWHX FLANGE HEAD CAP
3415347	CONNECTORFEMALE
3415328	CONNECTOR, FEMALE
5262986	GASKET, OIL DRAIN
3415608	BUSHINGREDUCING PIPE
3415680	HEADCORROSION RESISTOR
3966481	SUPPORTFILTER
3973898	DECAL