



Ben Liu
 Mobile/ WeChat: +86-13705041170
 FUZHOU SUNSHINE MACHINERY CO.,LTD
 NO.6 Gulouyuan, Juyuanzhou Industrial Zone,
 Jinshan Development Area, Fuzhou, Fujian, China.
 Email: sales@primepowergenset.com
<http://www.gensetengine.com>

Cummins KTTA19 engine Spare parts catalog

Part number	Description
2897690	SWITCH,PRESSURE
2897691	SWITCH,PRESSURE
216484	DIPSTICKBLANK
2888795	RETAINERCONTROL ROD
3081981	Tee, Male Union
4000637	PLUGTHREADED
3018785	PUMPWATER
3417958	COMPRESSOR, AIR
3010247	COV,VLV
3177713	HOUSING,ROCKER LEVER
3646325	HEADCYLINDER
3633046	SEALFERRULE
3202007	SHAFTWATER PUMP
3629505	TEESTREET PIPE
3037536	PLUG,THREADED
4967641	SUPPORT, AIR COMPRESSOR
100478	SEALO RING
4026171	GASKET,FUEL PUMP
BM76340	DAMPER,FUEL CONTROL
WF2076	WF PKG
3636821	MOTORSTARTING
207441	MANIFOLDFUEL
3084620	MANIFOLD, OIL
3870890	SEALOIL
3016792	SEAL,OIL 3016792
3176773	SHAFT, ROCKER LEVER
2867271	HOSEFLEXIBLE
4024767	KIT,LINER WITH RINGLINER SEAL 3088298

3347569	CRANKSHAFT, ENGINE
118346	UNIONMALE
3025887	SHAFTWATER PUMP
3032872	UNION, MALE
4922501	SEAL,O RING
3053478	LEVER,ROCKER
3053476	LEVER,ROCKER
3053477	LEVERROCKER
3630839	GASKET,RKR LEVER HOUSING
193736	SEAL,INJECTOR O RING
3521225	SCREWHEXAGON HEAD SET
3008706	SCREENINJECTOR FILTER
3803528	VALVEEXHAUST
3033665	BELTV RIBBED
3922794	SEAL,O RING
3800728	SETUPPER ENGINE GASKET
AR12270	Shell, Main Bearing (Standard)
3631241	PISTON ENGINE
3804935	KIT, LUB OIL CLR CVN
3076125	BARREL & PLUNGER,STEPPED
3056158	NUT, REGULAR HEXAGON
3018453	VALVE FUEL SHUTOFF
156810	BREATHER
3076489	THERMOSTAT
3400698	ALTERNATOR
207306	COVEROIL PAN ADAPTER
3007517	NOZZLEPISTON COOLING
212161	ORING
206996	BELTV RIBBED
107981	CAPFILLER
4307428	INJECTOR
3065697	TEE,STREET PIPE
3066882	CAMSHAFT
4024809	KIT,FUEL SOLENOID 4024809
3047549	PUMP,LUBRICATING OIL
186780	SEALTHERMOSTAT
175830	PLUGEXPANSION
3046283	SCREW, HEX FLANGE HEAD CAP
3046200	SPIDER,JAW COUPLING
3090450	RING,OIL PISTON
3090460	RING,COMPRESSION PISTON
4081176	RING,COMPRESSION PISTON
3081489	SEALOIL
3811995	RODENGINE CONNECTING
2888695	BEARINGTHRUST

3635074	CORE, COOLER
4998220	COVER, AFTERCOOLER
4910355	COREAFTERCOOLER
3642503	LEVER,CAM FOLLOWER 3081413
3078218	SHAFT,CAM FOLLOWER
S172B	SCREW,HEXAGON HEAD CAP
S173A	SCREW, HEXAGON HEAD CAP
S178C	SCREW,HEXAGON HEAD CAP
S181	
S181C	SCREW, HEXAGON HEAD CAP
S185A	SCREW, HEXAGON HEAD CAP
S189C	SCREW,SOCKET HEAD CAP
S199A	Hexagon Head Cap Screw
S199B	Screw, Hexagon Head Cap
S212	NUT,REGULAR HEXAGON
S223	NUT,HEAVY HEXAGON
S2286	DRIVE SCREW
S249	NUT,REGULAR HEXAGON JAM
S253	NUT,REGULAR HEXAGON JAM
S270	NUT,REGULAR HEXAGON
S316	KEY,PLAIN WOODRUFF
S500	PIN, COTTER
S600	WASHER,LOCK
S602	Washer, Plain
S603	WASHER,LOCK
S606A	WASHER, LOCK
S607	WASHER,LOCK
S608	WASHER,LOCK
S609	WASHER,LOCK
S610	WASHER,LOCK
S622	WASHER,PLAIN
S626	WASHER
S631	WASHER,PLAIN
S640	WASHER
S658	
S689	WASHER, PLAIN
S911B	PIPE, PLUG
S915A	PLUG,PIPE
S923E	DRAINCOCK
S955	BUSHING,REDUCING PIPE
S962E	DRAINCOCK
S963E	
100193	BUSHING
102397	STUD
102957	DOWELDIAMOND

103271	SCREWHEXAGON HEAD CAP
103426	GASKETAIR COMPRESSOR
105375	NAMEPLATE
108330	WASHER,PLAIN
108384	SLEEVESPRING PACK
108602	SCREW,HEXAGON HEAD CAP
109557	WASHERPLAIN
110058	NUTFUEL PUMP ADJUSTING
110481	LEVERGOVERNOR
111445	WASHER,LOCK
112105	ELBOWMALE ADAPTER
118226	SCREW,SOCKET HEAD CAP
118227	DOWELFUEL PUMP
118347	ELBOWMALE UNION
123204	SCREWHEXAGON HEAD CAP
124921	DOWEL, PIN
127018	WASHER,LOCK
127184	Washer, Plain
127362	WASHER,PLAIN
128807	RINGRETAINING
129069	NUTLOCK
129768	SPRINGVALVE
129838	KNOB
129839	COVER,SHUTOFF VALVE
129886	BODYFUEL SHUTOFF VALVE
129888	SEALRECTANGULAR RING
130083	BEARING, THRUST
130914	WASHERSEALING
131026	SEALO RING
132770	BUSHING
135231	PLUG EXPANSION
135530	RINGRETAINING
135783	WASHER,LOCK
137868	Screw, Hexagon Head Cap
137872	SCREW,HEXAGON HEAD CAP
138764	SCREW PAN HEAD CAP
143950	CONNECTORMALE
144378	ELBOWMALE ADAPTER
145504	SEALO RING
145536	SEAL, O RING
145540	SEALO RING
145551	SEALO RING
145623	SEALO RING
146483	SCREENROTOR
146517	NUTREGULAR HEXAGON

148554	DOWELPIN
153518	SEALRECTANGULAR RING
154087	SEAL,RECTANGULAR RING
158829	SCREW,HEXAGON HEAD CAP
163945	RINGRETAINING
165619	TUBEOIL GAUGE
167157	BALLCHECK
168306	SCREW,SLOTTED SET
172648	SEAL,RECTANGULAR RING
173086	GASKET,INJECTOR
174299	RETAINERINJECTOR FIL SCN
176288	TEEFEMALE ADAPTER
179904	CLAMPHOSE
3053772	PLUNGER, TAPPET
181213	ELBOW, PLAIN ADAPTER
181461	GOVERNORAIR COMPRESSOR
181466	WASHER,LOCK
3069102	GASKETAIR COMPRESSOR
3521034	WHEEL, TURBOCHARGER
3521442	SEAL,SPLIT RING
185848	GASKETAIR COMPRESSOR
190397	SLEEVEWEAR
191772	SCREW,TWELVE POINT CAP
192861	SCREWSOCKET HEAD CAP
194037	SOCKETROCKER LEVER
196057	DISCVALVE
3062393	SEALOIL
S1040A	ELBOW,MALE ADAPTER
200709	KEY, OFFSET WOODRUFF
AS16020NF	HOSE,FLEXIBLE
201989	CLAMP,V BAND
200861	WASHERPLAIN
3010918	GASKETTHERMOSTAT HOUSING
201007	CAPFUEL PUMP FILTER
3028324	VALVECHECK
201048	GASKETCONNECTION
3028325	VALVECHECK
201049	GASKET,CONNECTION
3063240	HOSE, PLAIN
202159	SCREWTWELVE POINT CAP
202682	HOUSINGSRING PACK
203310	WASHERPLAIN
203426	PIN,INJECTOR ROLL
203848	ELBOWMALE UNION
203933	PLUGEXPANSION

205021	CAPMAIN BEARING
205022	CAPMAIN BEARING
205023	CAPMAIN BEARING
205052	SHAFTIDLER
205059	WASHER,PLAIN
205061	GASKETLUB OIL PUMP
205065	SHAFTLUB OIL PUMP DRIVE
205075	CAPMAIN BEARING
205080	PLUNGERPRS REGULATOR
205091	COLLETVALVE
205093	INSERT,VALVE
205094	RETAINERVEALVE SPRING
205126	WASHERPLAIN
205128	WASHER,PLAIN
205129	DOWEL,RINg
205133	BUSHING
205140	BEARINGMAIN STD
205150	BEARINGMAIN STD
205156	BUSHING
205160	BEARINGMAIN STD
205170	BEARINGMAIN STD
205227	PLUG, EXPANSION
205243	IMPELLERWATER PUMP
205247	SEALO RING
205269	RINGRETAINING
205275	SCREWTWELVE POINT CAP
205288	GASKETWTR TRF CONNECTION
205354	SCREWTWELVE POINT CAP
205375	SCREWTWELVE POINT CAP
205378	SCREWTWELVE POINT CAP
205393	SCREW,TWELVE POINT CAP
205394	SCREW,TWELVE POINT CAP
205401	PLUGEXPANSION
205409	SCREWHEXAGON HEAD CAP
205438	LOCKWIRE
205439	RING,RETAINING
205840	Bearing, Connecting Rod (Standard)
205898	SEALO RING
4076956E836	PUMP,FUEL
206217	STUD
206218	STUD
206224	PLUG,EXPANSION
206256	PLUGTHREADED
206277	GASKET,INTAKE MANIFOLD
206279	GASKETCONNECTION

206326	SCREW,TWELVE POINT CAP
206332	SCREWTWELVE POINT CAP
206343	SUPPORTFRONT ENGINE
206402	SCREW, TWELVE POINT CAP
206576	GASKETTURBOCHARGER
3033667	SPACERMOUNTING
4851	GEARFLYWHEEL RING
206668	ELBOWPLAIN STREET PIPE
206881	SCREWTWELVE POINT CAP
206904	KEY,PLAIN WOODRUFF
206948	SEALOIL
206973	GASKETOIL COOLER CORE
207117	GASKETAIR COMPRESSOR
207214	PIPE, AIR INLET
207226	BUSHING
207233	TUBEWATER TRANSFER
207244	SEAL INJECTOR
207252	GEARLUBRICATING OIL PUMP
207344	BUSHING
207373	COVER,CAMSHAFT
207378	TUBEWATER TRANSFER
207442	CONNECTION, FUEL BLOCK
207527	SCREWTWELVE POINT CAP
208084	RIVET
209773	CLAMP,HOSE
212013	HEADFUEL FILTER
212147	
212350	PLUNGERGOVERNOR
60408	DOWELPIN
64929	STUD
67211	DOWEL, PIN
67622	PLUGPIPE
67684	WASHER,PLAIN
67946	WASHER,PLAIN
67950	CLIP
68050	WASHERPLAIN
68139	ELBOW,PLAIN ADAPTER
68143	CLIP
68152	CLIP
68445	PIN, GROOVE
68645	ELBOWMALE ADAPTER
68908	LOCKPLATE
69324	WASHERPLAIN
69521	BUSHING
69558	DOWELPIN

70620	WASHERPLAIN
70624	SEALO RING
70645	DOWELPIN
70690	PLUNGERFUEL CONTROL
70700	SPRINGFUEL PUMP TORQUE
70704	WASHER PLAIN
70760	DOWELPIN
70897	NUT,LOCK
212682	FANENGINE
213559	SOCKET,CAM FOLLOWER
213768	SEALO RING
213769	PLUGBALL
214139	BALL
217631	PLUGPIPE
218548	BARREL,GOVERNOR 218548
219065	BAFFLEBREATHER
553856	GASKETOIL DRAIN
3000174	HUBSPLINE COUPLING
3000266	SHAFT,SHUTOFF VALVE
3000446	COVERFUEL CONTROL
3000508	TUBEOIL GAUGE
3000528	NUTSPRING
3001280	RING
3001281	BEARINGROLLER
3001301	RETAINERSEAL
3001304	GASKETAFT HOUSING
3001305	GASKETCONNECTION
3001340	SEALO RING
3001663	GUIDEVALVE SPRING
3001811	SCREW,HEXAGON HEAD CAP
3002126	NUT,LOCK
3002158	PLUGPIPE
3002175	PULLEYCRANKSHAFT
3002179	TUBEWATER TRANSFER
3002183	HUBFAN
3002193	COVERFAN HUB
3002210	SPACERBEARING
3002211	SPACERBEARING
3002222	PULLEYFAN
3002323	PULLEYALTERNATOR
3002331	PULLEYALTERNATOR
3002834	BUSHING (CAMSHAFT)
3002886	SCREWHEXAGON HEAD CAP
3002993	DOWEL,RING
3003001	FLANGE

3003004	FLANGE
3003123	INSERTPUMP DRIVE
3003354	BEARINGROLLER
3003536	COUPLINGELBOW HOSE
3003755	BRACETUBE
3004057	NUTLOCK
3004293	PLUGFUEL PUMP DRAIN
4953331	GEAR, IDLER
3004685	GEAR, WATER PUMP
3004686	BUSHING
3004904	PLATECOVER
3005594	WASHERPLAIN
3005886	SEALOIL
3006343	STOPTHROTTLE LEVER
3006344	SCREWSQUARE HEAD SET
3007380	GASKETHYDRAULIC PUMP
3007632	PLUGEXPANSION
3007971	BEARING,CAMSHAFT THRUST
3008465	PLUGPIPE
3008466	PLUGPIPE
3008468	PLUGPIPE
3008469	PLUGPIPE
3008470	PLUGPIPE
3009109	PLATESWIRL
3009511	SUPPORTACCESSORY DRIVE
3009620	SPRINGENGINE BARRING
3010396	COVERROCKER LEVER
3010595	SCREWCAPTIVE WASHER CAP
3010597	SCREWCAPTIVE WASHER CAP
3010915	STUD
3010916	SUPPORTTHM HOUSING
3010922	CLIP
3010926	GASKETFLANGE
3010933	HOUSINGTHERMOSTAT
3011076	SEALO RING
3011224	TUBEWATER BYPASS
3011693	PLATECOVER
3011829	SCREWCAPTIVE WASHER CAP
3012467	WASHERPLAIN
3012472	SCREWCAPTIVE WASHER CAP
3012473	SCREWCAPTIVE WASHER CAP
3012474	SCREWCAPTIVE WASHER CAP
3012476	SCREWCAPTIVE WASHER CAP
3012481	SCREWCAPTIVE WASHER CAP
3013257	PLUGPIPE

3013265	SCREWCONNECTING ROD CAP
3013786	PLUGPIPE
3014103	WASHER PLAIN
3014668	SEALO RING
3014695	PULLEYACCESSORY DRIVE
3014766	SCREW,CAPTIVE WASHER CAP
3015067	SEALO RING
3015283	SCREWCAPTIVE WASHER CAP
3015525	RINGRETAINING
3016794	SEALOIL
3016825	ROLLERCAM FOLLOWER
3016826	ROLLERCAM FOLLOWER
3017276	HOSEPLAIN
3017346	WASHERPLAIN
3017961	RODPUSH
3018047	SCREWFILLISTER HEAD CAP
3018310	BUSHINGREDUCING PIPE
3018914	GUIDEBARRING SHAFT
3018924	WIRE,GROUND
3019152	GEARENGINE BARRING
3019153	SHAFTBARRING
3019961	NUTPLUG
3020523	COVERGOVERNOR DRIVE
3021470	SCREWCAPTIVE WASHER CAP
3021977	COVERSPRING PACK
3022590	SCREWCAPTIVE WASHER CAP
3023066	SEAL,O RING
3023095	WASHER SEALING
3023217	PLUG,THREADED
3025458	PLUGPIPE
3025460	PLUG, PIPE
3025482	SCREW TWELVE POINT CAP
3025695	HOUSINGFUEL PUMP GEAR
3026296	INSERTVALVE
3026556	BEARING, THRUST
3026793	CLIP
3027240	FLYWHEEL
3027633	BEARINGTHRUST
3028064	GASKETAFTERCOOLER COVER
3028291	SEAL,O RING
3029631	CLAMP, V BAND
3030274	COVERFUEL PUMP
3031404	CONNECTOR, TUBE
3032161	GASKETCONNECTION
3032633	SCREW,TWELVE POINT CAP

3033023	ELBOWMALE UNION
3033024	ELBOWMALE UNION
3033038	SCREWCAPTIVE WASHER CAP
3033098	BRACETUBE
3033822	SCREWCAPTIVE WASHER CAP
3034243	PUMPGEAR FUEL
3034451	HOUSINGACTUATOR
3034452	DISC,ACTUATOR
3034721	RETAINERSHAFT
3035228	SEALO RING
3035230	BEARINGTHRUST
3035310	WASHERPLAIN
3035580	HOSE, FLEXIBLE
3035624	SCREW, CAPTIVE WASHER CAP
3035738	VALVESHUTOFF
3036137	SPINDLEFAN
3036666	SEALO RING
3037537	SEAL,O RING
3037657	CONNECTIONOIL SUPPLY
3037658	BRACKETSHUTOFF VALVE
3037660	TUBELUB OIL DRAIN
3037662	ELBOW,MALE UNION
3037824	MANIFOLDEXHAUST
3038668	BODYFUEL PUMP AFC
3038743	VALVE, CHECK
3038763	SEAL,O-RING
3038938	COVER,ROCKER LEVER
3039164	LEVER,CAM FOLLOWER
3040721	GASKETCAM FOL HOUSING
3040722	GASKETCAMSHAFT COVER
3040750	PLUNGERGOVERNOR
3040760	PLUNGER,GOVERNOR
3040818	PLUGTHREADED
3040837	SCREWCAPTIVE WASHER CAP
3040838	Screw
3040839	SCREWCAPTIVE WASHER CAP
3040878	CLAMP, T BOLT
3041859	SUPPORTALTERNATOR
3042329	WASHERPLAIN
4307427	ADAPTER,INJECTOR
3042427	SPRING,COMPRESSION
3042428	SPRING,COMPRESSION
3042430	RETAINERINJECTOR CUP
3042586	GASKETHAND HOLE
3042590	GASKETOIL PAN

3042612	GASKETFAN HUB
3042827	SHAFT, WATER PUMP
3042889	SCREWCAPTIVE WASHER CAP
3042890	SCREWCAPTIVE WASHER CAP
3043097	GASKETEXHAUST MANIFOLD
3043909	Bushing, Connecting Rod
3044413	SCREWCAPTIVE WASHER CAP
3045025	PLUGINJECTOR ORIFICE
3045136	WASHERPLAIN
3045137	SCREWHEXAGON HEAD CAP
3045229	SHAFTACCESSORY DRIVE
3046201	SEALO RING
3046202	PLUG,THREADED
3046407	SCREWSOCKET SET
3046680	SHAFTTHROTTLE
3047340	ELBOWMALE UNION
3048557	SPACER,BEARING
3049016	SLEEVE, EXHAUST CONNECTION
3049543	GEAR LUBRICATING OIL PUMP
3052218	RETAINER,INJECTOR SPRING
163654	SEALO RING
166619	STRAINER, AIR
176027	GASKETAIR COMPRESSOR
177269	ENDCONTROL ROD
199358	SLEEVESPLINE COUPLING
203131	NUTHEAVY HEXAGON
204995	ELBOWMALE ADAPTER
205049	BODY, LUBRICATING OIL PUMP
205057	BODYLUBRICATING OIL PUMP
205141	BEARINGMAIN 010
205142	BEARINGMAIN 020
205143	BEARINGMAIN 030
205151	BEARINGMAIN 010
205152	BEARINGMAIN 020
205153	BEARINGMAIN 030
205161	BEARINGMAIN 010
205162	BEARINGMAIN 020
205163	BEARINGMAIN 030
205169	GUIDEVALVE CROSSHEAD
205171	BEARINGMAIN 010
205172	BEARINGMAIN 020
205173	BEARINGMAIN 030
4095009	PIN, PISTON K
205258	RINGRETAINING
205301	SFT,FOL

205363	WASHERSPRING
205366	DOWELDIAMOND
205731	SUPPORTFRONT ENGINE
205791	GASKETSCAVENGE PUMP
206202	NUT
206354	SCREWHEXAGON HEAD CAP
206446	GASKET WTR TRANSFER TUBE
206963	INSERTFILTER HEAD
207038	SEALO RING
207075	GASKET WATER BYPASS TUBE
207135	SEAL,RECTANGULAR RING
207251	GER,PMP
207253	
207279	PUMP, LUBRICATING OIL
218893	BOSS
2888640	SEAL,RECTANGULAR RING
3000438	
3002330	GASKETACC DRIVE SUPPORT
3004249	CONNECTION, WATER OUTLET
3004599	GEAR
3004680	GER,PMP
3006430	*
3007803	IDLER GEAR, MTG
3008403	GASKETOIL SUC CONNECTION
3009089	HEAD, CYLINDER
3009955	COVER, LUB OIL PUMP
3010536	SHAFTSHUTOFF VALVE
3010925	FLANGE, WELD
3011575	UNITSENDING
3013222	SCREWHEXAGON HEAD CAP
3013962	HEAD, CYLINDER MTG
4986318	DRIVE, ACCESSORY
3016789	SEALOIL
3016791	SEALOIL
3018909	BUSHING
3019154	GUIDEBARRING SHAFT
3019794	VALVECHECK
3019795	TACHOMETER
3023129	SEAL,DUST
3026421	SEALO RING
3026564	SHAFT, WATER PUMP
3027988	RINGRETAINING
3279805	LINKINJECTOR PLUNGER
3029820	SEALO RING
3031298	ACTUATOR

3032697	SCREWCROSSHEAD ADJUSTING
3032862	TUBETUR OIL DRAIN
3032864	CONNECTIONAIR CROSSOVER
3033666	HUBFAN
3803529	K VLV,EXH
3035299	TUBELUB OIL SUCTION
3035739	BODYSHUTOFF VALVE
3035740	COVERSHUTOFF VALVE
3035823	SPRINGFUEL PUMP TORQUE
3036096	BRACEWATER PUMP
3036900	WASHERPLAIN
3037214	HEAD, CYLINDER
3040810	
3040819	PLG,THD
3040995	PLUGTHREADED
3041466	DISCACTUATOR
3042330	WASHERPLAIN
3042372	COVERTOR CNV OIL COOLER
3044521	PLATE, GEAR COVER
3045047	PLUG, INJECTOR ORIFICE
3046943	SEAL O RING
3047341	CAPTUBE
3047548	COVERLUB OIL PUMP
3048688	TUBE EXHAUST OUTLET
3050897	PLG,THD
3053502	BARREL, INJECTOR
3054852	SPRINGCOMPRESSION
3056003	PLG,THD
3056356	HARNESSWIRING
3056415	SEALO RING
3056416	PLUGTHREADED
3056508	SCREWDRIVE
3056787	CLAMP, HOSE
3057139	RODPUSH
3060567	SCREWCAPTIVE WASHER CAP
3060912	GASKET, CONNECTION
3060940	BRACERETAINING
3062410	SCREWHEXAGON HEAD CAP
3062415	SPRINGCOMPRESSION
4327021	SWITCH,TEMPERATURE
3065783	CONNECTION,AIR INTAKE
3065784	GASKET, CONNECTION
3065785	CONNECTIONAIR INTAKE
3065790	GASKETLUB OIL CLR HSG
3065791	GASKETTOR CNV OIL COOLER

3065792	GASKETTOR CNV OIL COOLER
3065801	HOSEPLAIN
3065803	Thermostat Housing
3065830	SEALOIL
3065839	Plumbing, Hvt Oil Supply
3065944	SCREW,CAPTIVE WASHER CAP
3065950	SCREWCAPTIVE WASHER CAP
3066497	SCREWHEX FLANGE HEAD CAP
3067168	SPACERMOUNTING
3067880	HARNESSWIRING
3068859	CAP,TAPPET TOP STOP
3068860	NUTLOCK
3069846	COVERHAND HOLE
3069847	COVERHAND HOLE
3070679	SCREWHEXAGON HEAD CAP
206808	SEAL,GROMMET
3070854	BRACKETFILTER
3070962	SCREW HEXAGON HEAD CAP
4308738	HOSE FLEXIBLE
3071085	SEALWATER PUMP
3073120	NAMEPLATE MTG
3073213	GASKETOIL PAN COVER
3073218	COVER, GEAR
3074681	CONNECTIONWATER INLET
3074682	TUBEWATER INLET
3074684	TUBEWATER OUTLET
3074690	GASKETGEAR COVER
3075381	TAPPET,HYD VAR TIMING
3076124	
3076301	CLAMPWIRE TIE
3078053	SCREWCAPTIVE WASHER CAP
3079754	GASKETOIL SUC CONNECTION
3080980	MANIFOLDEXHAUST
3081040	DAMPER, VIBRATION
3081064	HEAD, CYLINDER
3640315	ROTATOR, VALVE
3081507	PLUNGERFILTER HEAD
3081620	COVERCAMSHAFT
3081621	GASKETCAMSHAFT COVER
3081794	HOUSINGFLYWHEEL
3081950	UNION,MALE
3081951	ELBOWMALE UNION
3084539	SEAL,O RING
3085345	SOCKET, TAPPET
3085733	CONNECTIONWATER BYPASS

3085751	SCREWHEXAGON HEAD CAP
3085752	SCREWHEXAGON HEAD CAP
3085753	SCREWHEXAGON HEAD CAP
3085821	ELBOW, MALE UNION
3085886	WASHERPLAIN
3085955	HOUSINGOIL COOLER
3086035	CONNECTIONWATER INLET
3086055	HOSEFLEXIBLE
3086149	TUBEWATER TRANSFER
3086169	CONNECTION, WATER INLET
3086177	SUPPORTWATER PUMP
3086191	INSERTVALVE
3086192	INSERTVALVE
3086244	HOUSING, BELT TENSIONER
3086251	RETAINERSPRING
3086252	PIN, CLEVIS
3086269	SPRINGCOMPRESSION
3086278	WASHERPLAIN
3086362	CROSSHEAD, VALVE
3088256	PANOIL
3088291	WASHERPLAIN
3088297	BRACKETFILTER
3088298	RINGLINER SEAL
3088301	BLOCK, CYLINDER
3088311	KIT, LINER
3088317	LOCKPLATE
3088371	SEAL, DUST
3088374	BRACKETOIL TUBE
3088380	RING, LINER SEAL
3088411	BRACERETAINING
3088418	CLIP
2888887	TENSIONER, BELT
3090194	SEAL, DUST
3090441	SPRINGVALVE
3090449	HOUSINGTOR CNV COOLER
3095293	UNIONMALE
3096260	SEAL, RECTANGULAR RING
3160923	ADAPTEROIL PAN
3160924	SEALDUST
4334080	GASKET, CYLINDER HEAD
3176619	HEAD, CYLINDER
3630452	GASKET, TURBOCHARGER
3179021	SCREW, BANJO CONNECTOR
3179027	GASKETCONNECTION
3200069	BRACKETCHECK VALVE

3200070	BRACKETCHECK VALVE
3200158	TUBETUR OIL DRAIN
3200215	CONNECTION, WATER PUMP
3200281	WASHERPLAIN
3200287	SEALKEYWAY
3200386	CLAMP TUBE
3200387	CLAMP TUBE
3200393	CLIP
3200404	TUBE, FUEL SUPPLY
3200413	BRACKETOIL TUBE
3200457	TUBEFUEL DRAIN
3200642	PLATECLAMPING
3200706	CLIP
3200772	WASHERPLAIN
3200781	PLUG, DRAIN
3200783	PLATECOVER
3200842	TUBEFUEL DRAIN
3200934	PLUGRETAINER
3200968	PLUGTHREADED
3200976	COVERCAMSHAFT
3200977	GASKETLUB OIL FIL COVER
3201056	COVERFLYWHEEL HOUSING
3201060	COVERHAND HOLE
3201074	TUBE, FUEL DRAIN
3201087	TUBEFUEL DRAIN
3201115	TUBEFUEL SUPPLY
3201117	STUD
3201125	SEALO RING
3201128	NUT,REGULAR HEXAGON
3201188	LINK,ADJUSTING
3201206	PLUGEXPANSION
3201228	PULLEYIDLER
3201287	CLIP
3201384	Hose, Flexible
3201388	GASKETFLANGE
3201401	HOSEPLAIN
3201583	PLUG,THREADED
3201585	SEALO RING
3201614	SPACERMOUNTING
3201659	SEALRECTANGULAR RING
3410171	GSK,SPT
3201759	SCREWHXAGON HEAD CAP
3201850	GSK,CPR
3202101	PLUGTHREADED
3202114	SHAFT, IDLER

3202117	GASKETCONNECTION
3202162	WIREGROUND
3202181	SUPPORTTURBOCHARGER
3202198	HOUSINGROCKER LEVER
3202206	NUTLOCK
3202210	GUIDEVALVE STEM
3202220	TUBE, PRESSURE SENSING
3202283	GASKETWATER PUMP
3275479	SCREWHEXAGON HEAD CAP
3279720	CUP,INJECTOR
3279794	SEALINJECTOR O RING
3279821	SCREWINJECTOR STOP
3279850	NUTTAPPET TOP STOP LOCK
3304173	HEAD, LUB OIL FILTER
4371702	BUSHING
3648162	SEAL, DUST
3347739	HOUSINGAFTERCOOLER
3402156	GUIDESPRING
3410132	SUPPORTPIVOT SHAFT
3410133	SUPPORTPIVOT SHAFT
3410134	LEVERIDLER
3410141	GASKETCOVER PLATE
3411695	CLAMPINJECTOR
3502449	SEAL,RECTANGULAR RING
3504967	WASHERPLAIN
3519163	SCREWDRIVE
3519535	NUTLOCK
3519627	Bearing, Turbocharger
3519641	RINGRETAINING
3521265	HOUSINGTURBINE
3522597	PINROLL
3522631	CLAMPV BAND
3522904	LOCKPLATE
3523024	IMPELLER, TURBO HC5A
3523412	SEALSPLIT RING
3523546	IMPELLER, TURBO HC5A
3523556	HOUSINGCOMPRESSOR HC5A
3523980	SLINGEROIL
3524418	SHIM
3524419	BAFFLEOIL
3524421	DIFFUSER, TURBOCHARGER
3524863	DIFFUSERTURBOCHARGER
3525073	SCREWHEXAGON HEAD SET
3525076	HOUSINGCOMPRESSOR HC3
3527619	DATAPLATE

3528109	CLAMPV BAND
3529372	NUTREGULAR HEXAGON
3529706	HOUSINGTURBINE
3536588	SHIELDTURBOCHARGER HEAT
3536914	BEARINGTUR THRUST
3591522	COLLARTHURST
3594111	TURBOCHARGER
3594555	Housing, Tur Bearing
3625504	BULBLIGHT
3627044	CONNECTIONOIL TRANSFER
3627697	
3628411	COVERSTARTER FLANGE
3628755	COVER,CAMSHAFT
3628756	COVER,CAMSHAFT
3628894	SEALDUST
3628895	SEALOIL
4920076	GASKET,ROCKER LEVER COVER
3629962	WASHER,PLAIN
3643725	SPRING,VALVE
3635250	PINGROOVE
3800192	KIT, PDC
3800264	KIT, PDC
3800726	SETSINGLE HEAD GASKET
3801803	TURBOHC5A
3803257	KITTUR REPAIR
3803452	TURBO,HC5A
3804700	KIT,STC TAPPET REPAIR
3088303	BLOCKCYLINDER
3811992	TUBELUB OIL SUPPLY
3811993	TUBELUB OIL TRANSFER
3818271	HOSEPLAIN
3818885	SEAL,O RING
3883200	PLUGTHREADED
3883200	PLUG, THREADED
3888312	CHEM. PKG. DCA65-L
LF670	LF PKG A
3938655	GASKETACC DRIVE COVER
3945095	PLUGEXPANSION
3991084	NAMEPLATE
4000504	SEALRECTANGULAR RING
4000574	BRACETUBE
4000595	GASKETOIL PAN ADAPTER
4009247	PINCAM FOLLOWER ROLLER
4009248	PINCAM FOLLOWER ROLLER
4009433	SHAFTIDLER

4009442	LEVERIDLER
4024773	KITLINER
4057646	BRACKETBELT TENSIONER
4077027	
4081087	BODYWATER PUMP
4081095	PUMP, WATER
4094865	SEALRECTANGULAR RING
43828A	CLAMP,HOSE
4910284	HEADLUB OIL FILTER
4910287	
4910518	SEALRECTANGULAR STRIP
4922336	TUBE,WATER OUTLET
4931643	PLUG,PIPE
4953326	GEAR, IDLER
4953328	GEAR, IDLER
4953329	Gear, Idler
4998542	SEAL,O RING
60408L	DOWELPIN
68138	CONNECTOR,MALE
68209	GASKETBYPASS VALVE BODY
70183	RINGRETAINING
70772A	SCREWFILLISTER HEAD CAP
9226	DWL,PIN
AF25708M	
AK10007SS	HOSE,
AK6008SS	HOSE
AR70577	PDC Kit
S1003A	SEAL, GROMMET
S1004A	NUT, TUBE
S1039A	CONNECTOR, MALE
S103A	SCREW,HEXAGON HEAD CAP
S103C	SCREW, HEXAGON HEAD CAP
S103D	SCREW,HEXAGON HEAD CAP
S1042A	TEE,MALE ADAPTER
S105	SCREW,HEXAGON HEAD CAP
S106	SCREW,HEXAGON HEAD CAP
S106C	SCREW,HEXAGON HEAD CAP
S112	SCREW,HEXAGON HEAD CAP
S113	
S114	
S116	SCREW,HEXAGON HEAD CAP
S123A	SCREW, HEXAGON HEAD CAP
S125	SCREW,HEXAGON HEAD CAP
S126	Screw, Hexagon Head Cap
S127C	Screw, Hexagon Head Cap

S129	SCREW, HEXAGON HEAD CAP
S141	
S156B	SCREW, HEXAGON HEAD CAP
S159B	
S16002	BEARING, BALL
S16069	BEARING, BALL
S16240	
S163	SCREW, HEX HEAD CAP
3040809	PLUG, THREADED
3921724	TAG, IDENTIFICATION
3015521	BALL
S169A	SCREW, HEXAGON HEAD CAP
205069	LEVER, CAM FOLLOWER
3630034	PLUG, THREADED 3023217
3006175	SCREW, FUEL PUMP ADJUSTING
68061A	SEAL, O RING
3166289	GASKET, CYLINDER HEAD
4000506	DATAPLATE
206231	LEVER, CAM FOLLOWER
4953319	GEAR, CRANKSHAFT
205202	GEAR & SHAFT
205077	GEAR & SHAFT
3201187	LINK, ADJUSTING
3018910	BEARING, THRUST
206804	FLYWHEEL
3069844	SEAL, RECTANGULAR STRIP
3811994	ROD, ENGINE CONNECTING
3803515	VALVE, INTAKE
3826824	DECAL
3086178	SUPPORT, WATER PUMP
3201185	BOLT, EYE
3201186	BOLT, EYE
S171S	CAPSCREW
AK6056SS	HOSE, FLEXIBLE
3033799	SUPPORT, ALTERNATOR
3086249	SCREW, HEXAGON HEAD CAP
4067334	END, CONTROL ROD
3201078	COVER, FLYWHEEL HOUSING
3017472	DRIVE, ACCESSORY MTG
FP4967	HOUSING, FUEL PUMP
145505	SEAL, O RING
70775	SEAL, O RING
3331554	PISTON & CONN ROD
3646323	HEAD, CYLINDER
205208	SPRING, VALVE

3047708	HOUSING, ROCKER
3039100	ASSY, ROCKER LEVER HOUSING
3065786	CONNECTION, AIR INTAKE
3408607RX	SWITCH PRESSURE
3408631RX	SWITCH, TEMPERATURE
3053476RX	LEVER ROCKER
3086362RX	CROSSHEAD, VALVE
3018453RX	VALVE FUEL SHUTOFF
3017961RX	RODPUSH
3011826	PULLEYACCESSORY DRIVE
3801195	